


Breakdown Sheet
Riveting – Pistol Grip
Model 40000 Air Hammer Instructions & Parts



Item	Part Number	Description	Item	Part Number	Description
1	73100	Pistol Handle	11	73202	Throttle Stem
2	240202	Barrel	12	73500	Small Rubber Seal
3	240600	Piston	13	73700	Trigger Washer
4	240301	Front Valve Block	14	73800	Elastic Stop Nut
5	241800	Wafer	15	73300	Trigger Body
6	240501	Back Valve Block	16	73400	Larger Rubber Seal
7	240700	Pin (2 req.)	17	73900	Trigger Lever Pin/Washer
8	153600	Socket Set Screw	18	73600	Trigger Depressor Lever
10	4700	Beehive Spring	19	76000	Inlet Bushing